

Setback Distances in feet
 Freeborn County, Minnesota Table date: March 6, 2012

Map Unit Symbol	Drain Depth, feet			
	2	3	4	5
102B	50	70	90	110
102C	50	70	90	110
104B	50	50	70	80
104C	50	50	70	80
1055	50	60	70	90
106B	50	60	80	90
106C2	50	60	80	90
110	50	60	80	90
112	50	50	60	80
113	50	60	80	90
114	50	60	70	90
123	50	60	70	80
129	90	165	230	285
130	50	80	90	110
134	50	70	90	100
136	60	90	110	130
138B	50	80	100	120
138C2	50	80	100	120
140	70	100	120	150
154	70	100	130	160
156	170	300	400	400
156B	170	300	400	400
160	90	140	190	240
1805	100	140	160	190
1806	50	80	100	120
1806B	50	80	100	120
1818	50	220	300	380
183	120	220	300	380
190	150	260	360	400
216B	70	130	180	230
216C	70	130	180	230
227	130	220	290	360
229	50	70	90	110
23	50	60	70	80
238B	50	80	100	110

Notes: 1) These setback distances are only for the situation where a drainage system will be installed and the landowner wishes to avoid impacting the wetland hydrology. 2) These values assume the ponded water on the site is 0.25" or less. 3) The effective depth of the drain (ditch or tile) is the elevation difference between the ground surface at the approximate setback distance and the water surface in the drain, or the bottom of the drain if it typically has no standing water.

Setback Distances in feet
 Freeborn County, Minnesota Table date: March 6, 2012

	50	80	100	110
238C2	50	80	100	110
239	50	60	80	90
247	125	210	280	310
24B	50	50	60	70
252	140	260	360	400
253	50	60	70	90
255	110	200	270	340
259B	60	90	120	140
259C	60	90	120	140
27	90	150	200	250
27B	90	150	200	250
27C	90	150	200	250
282	130	240	330	400
286B	50	70	90	100
286C2	50	70	90	100
287	50	70	90	110
300	120	220	300	380
318	110	200	270	340
35	70	100	130	160
350	50	60	80	90
376B	50	70	90	100
377	50	60	80	90
378	50	50	60	70
380	50	60	80	90
381	50	60	70	90
382B	60	80	100	120
382C	50	60	80	90
386	60	90	110	130
391	70	100	120	150
392	120	240	340	400
393	170	300	390	400
400	60	90	110	130
41	140	230	300	370
414	50	50	70	80
41B	140	230	300	370
41C	140	230	300	370
444	50	70	80	100
447	50	80	100	120

Notes: 1) These setback distances are only for the situation where a drainage system will be installed and the landowner wishes to avoid impacting the wetland hydrology. 2) These values assume the ponded water on the site is 0.25" or less. 3) The effective depth of the drain (ditch or tile) is the elevation difference between the ground surface at the approximate setback distance and the water surface in the drain, or the bottom of the drain if it typically has no standing water.

Setback Distances in feet
 Freeborn County, Minnesota Table date: March 6, 2012

	465	110	210	300	370
5	130	250	350	400	
517	70	170	250	330	
518	200	300	380	400	
519	50	60	80	90	
521	50	250	330	400	
524	200	250	250	250	
525	50	110	140	170	
539	50	70	90	120	
5B	130	250	350	400	
5C	130	250	350	400	
62	60	80	100	120	
83	50	60	70	90	
84	50	60	80	90	
86	50	60	80	90	
87B	110	180	230	290	
920B	50	70	90	110	
920C	50	70	90	110	
921B	50	70	90	110	
921C	50	70	90	110	
925	50	60	70	80	
940	50	60	70	90	
944B	50	60	80	90	
944C2	50	60	80	90	
94B	50	70	90	110	
L13A	50	90	120	140	
L83A	50	60	80	90	
L84A	50	60	70	90	
L85A	50	60	80	100	

Notes: 1) These setback distances are only for the situation where a drainage system will be installed and the landowner wishes to avoid impacting the wetland hydrology. 2) These values assume the ponded water on the site is 0.25" or less. 3) The effective depth of the drain (ditch or tile) is the elevation difference between the ground surface at the approximate setback distance and the water surface in the drain, or the bottom of the drain if it typically has no standing water.